


Wrinkle manual measurement gauge

Description

Wrinkle rating is a critical measurement when assessing if a can is airtight hermetically sealed. One way to measure this is to do a manual inspection and assess the value of the wrinkle measurement. A can will often leak if it does not meet its wrinkle rating specifications.

The wrinkle attachment to the [SEAMetal HD](#) system allows the operator to measure wrinkle ratings manually using the SEAMetal optical unit.

Please contact us for technical details regarding this option.




Wrinkle manual measurement gauge

Description

Wrinkle rating is a critical measurement when assessing if a can is airtight hermetically sealed. One way to measure this is to do a manual inspection and assess the value of the wrinkle measurement. A can will often leak if it does not meet its wrinkle rating specifications.

The wrinkle attachment to the [SEAMetal HD](#) system allows the operator to measure wrinkle ratings manually using the SEAMetal optical unit.

Please contact us for technical details regarding this option.




Wrinkle manual measurement gauge

Description

Wrinkle rating is a critical measurement when assessing if a can is airtight hermetically sealed. One way to measure this is to do a manual inspection and assess the value of the wrinkle measurement. A can will often leak if it does not meet its wrinkle rating specifications.

The wrinkle attachment to the [SEAMetal HD](#) system allows the operator to measure wrinkle ratings manually using the SEAMetal optical unit.

Please contact us for technical details regarding this option.



Wrinkle manual measurement gauge

Description

Wrinkle rating is a critical measurement when assessing if a can is airtight hermetically sealed. One way to measure this is to do a manual inspection and assess the value of the wrinkle measurement. A can will often leak if it does not meet its wrinkle rating specifications.

The wrinkle attachment to the [SEAMetal HD](#) system allows the operator to measure wrinkle ratings manually using the SEAMetal optical unit.

Please contact us for technical details regarding this option.

